



'The Window Frame Experts!'

Product Directions

2.5oz 'Liquid PVC' Vinyl Adhesive

CAP REMOVAL AND OPENING

1. Remove red cap, nozzle and red spacing ring. (see Fig. 1a and 1b)
2. Discard red spacing ring.
3. Screw and tighten red cap and nozzle to break the seal on the top of tube. (see Fig. 2)
4. Remove cap to check that the aluminum seal has been punctured and liquid can flow free. (see Fig. 3)
5. If seal has been properly punctured, screw red cap and nozzle back on and the tube is ready for use.



Figure 1a



Figure 1b



Figure 2



Figure 3

PRODUCT APPLICATION

1. Clean and dry all vinyl surfaces before applying 'Liquid PVC.'
2. Place a continuous bead over the gap and let cure. Total cure time usually takes between 3 and 24 hours depending on the temperature and width or depth of the gap.
3. To extend product lifespan, reseal the nozzle with red cap after use.
5. Once cured, the hardened 'Liquid PVC' will be similar in consistency to the original rigid PVC material. Recommend removing excess PVC after it is completely cured.
6. Once excess is removed, vinyl can be sanded and polished. We recommend using VinylDoc's Shine-It pads to remove scratches and restore the desired sheen.
7. For product tutorials with regards to specific repair situations, please visit vinyldoc.com.